

Maintenance Instruction - Chamber

Chamber:

MuoviTech always prefers to have drainage pipes mounted on a manhole on an existing connection.

If the drain pipe is NOT installed, check that the well does not have too much condensation. Condensation is constantly forming on the surface of all the pipes inside the well.

If there is a lot of water, use a wet vacuum cleaner or drain pump, empty out the well.

Valves:

(Examples of valves)



Shut-off valves/butterfly valves should be tested 1 time/year

- Turn the handle to close the valves and turn back quickly.

Balancing and bleed valves should NOT be tested without professional experience

Cover/Manholes:

- Open the lid 1 time/year and clean the gasket. In the case of Cover (cast iron), pebbles are sometimes pressed down. This causes water to leak into the chamber.
- In case of wear and tear of the gasket, it is suggested that You replace the gasket.
New ones can be ordered from www.muovitech.com

